




Lights



- Use the on **ON** and off **OFF** buttons to turn the lights off or on.
- Use the up **▲** and down **▼** buttons to dim the lights. You can either press and hold the appropriate button to adjust the impact or press it several times.
- If you have any problems controlling the lights, you can “reset” them by pressing on and off simultaneously. This will turn the lights off. You can then use the buttons normally to resume control.



Blinds



- Most blind control panels are near the windows. Please note, a room may have both blackout and light filtering shades. Blackout shades will be labeled as “Blackout.” Light filtering shades will be labeled as “Filtering.”
- To have a shade come down automatically, press the shaded button at the **bottom** of the panel. Press the button again to stop the process.
- To have a shade retract automatically, press the empty button at the **top** of the panel. Press the button again to stop the process.
- Use the center buttons to move the blinds up or down manually.

Projection Screens



- To move the screen down, press the down button.
- To move the screen up, press the up button.
- To stop the screen, press the stop button.